

MANUAL PULL DOWN PROJECTION SCREEN

TO RAISE AND LOWER MANUAL PROJECTION SCREEN:

- ➔ Hold wire knob and pull down screen
- ➔ Hook wire knob to screw located in wood of chalkboard base to keep screen lowered
- ➔ To pull screen back up, take wire knob off hook; screen will roll back up