

## ☐ AUTOMATIC PROJECTION SCREEN ☐

### ☐ **TO RAISE AND LOWER AUTOMATIC PROJECTION SCREEN:**

- ➔ Use wall switch; press **DOWN** to lower screen and **UP** to raise screen
  - Projection screen control switch is located next to stairwell entrance to classroom around wall from Judge's podium